

Instructions

- 1) Print and cut out the ruler.

IMPORTANT: This file must be printed actual size (100%). Printer output options such as "Fit to Page" and "Shrink Oversized Pages" will distort the ruler size and affect its accuracy.

- 2) Cut out the center section labeled, "CUT OUT THIS AREA".
- 3) Tape the end of the ruler (where indicated) so that it is perpendicular to the pipe being measured.
- 4) Wrap the ruler snugly around the pipe and back onto itself. The blue line at the taped end should be visible through the cut-out center window and should line up with the appropriate clamp size for your installation.
- 5) Purchase measuring calipers to aid in future installations.

